
# SERVICE MANUAL

AUDIO TIMER

# SANSUI AT-15B AT-158





SANSUI ELECTRIC CO., LTD.

### **SPECIFICATIONS**

Clock type . . . . . . 24-hour digital clock

Indication accuracy  $\ \ \, . \ \ \,$  . Within  $\pm 10$  seconds a month

(AC power supply synchronizing

system)

On/off preset timer

Preset . . . . . On/off time can be preset at will be

units of minute.

Timer accuracy . . . Within  $\pm 0.02$  second of the set time Time of up to 1 hour 59 minutes Sleep timer . . . . .

can be set at will by units of minute

Capable of counting up to 1 hour Timer counter .

59 minutes 59 seconds 1 count for 1 second Indication is available in minute/second and hour/minute

modes.

AC outlet . . . . . 2 outlets, 700 W in total.

Power supply voltage  $\,$  . 110 to 120 V/220 to 240 V

(with the power supply voltage

selector switch).

Power supply frequency

. . . . . . . . . . . 50/60 Hz (with the frequency

selector switch).

Power consumption . .

Dimensions


270 mm (10-11/16") W 71 mm (2-13/16") H 121.5 mm (4-13/16") D

Weight

1.2 kg (2.6 lbs.) net 1.5 kg (3.3 lbs.) packed


\*Design and specifications subject to change without notice for improvements.

# 1. PARTS LOCATION & PARTS LIST




# 1-1. IC & Display Unit Circuit Board (AT-15XX-001)

Note: The circuit board, AT-15-001/AT-15-002 are not supplied as the assembled, the individual parts on the circuit board, however, are provided for orders.



## 1-2. Power Supply & Push Switch Circuit Board (AT-15XX-002)




Parts List (Phots-1, 2, 3/ Circuit Board 1-1, 1-2)

Parts No.	Stock No.	Description
•Transistor TR1,2	03059502	2SC945
•IC LSI1	03612100	MN6076
	03117400 03111800	1N4002 1S1588
ZD01	03162900	RD12EB
DS1	00000200	Display Unit
RY	11505800	Relay
SS 1	11104100	AC Frequency Selector Switch

Parts No.	Stock No.	Description
RS1	11019400	Function Switch
RS2	11019500	Outlet Control Switch
T 1	40031400	Power Transformer
PS 1 ~ 4	11320400	Push Switch
CN1,2	24501100	AC Outlet
	38004701	AC Cord
	07108700	Front Panel Ass'y B
	07108100	Front Panel Ass'y S
	(53967900	Smoked Plate
	53967700	Knob Guide B
	153967800	Knob Guide S
	03191200	
	00.0.00	Selector Knob B
	07108000	

Parts No.	Stock No.	Description
	53194800	Push Knob B
	53194900	Push Knob S
	55173400	Leg
	52965300	Display Unit Holder
	50070000	Bonnet
	39108200	Strain Relief, AC Cord
SS 2	11104200	Slide Switch, power supply voltage selector
	52970600	Switch Stopper


Since there are AT-15B & AT-15S in the parts list above, please pay attention when ordering Parts. Parts marked (B) in parts list . . . . . for AT-15B only . . for AT-15S only Parts marked (S) in parts list . . .



### REPLACEMENT OF IC & DISPLAY UNIT

- Remove bonnet and front panel ass'y.
- Take out IC and dispaly unit to this side.

  Take off dispaly unit holder at both sides then replace the IC to lean dispaly unit toward this side. (The leads of dispaly unit do not break off if the bending is within few times).



SANSUI ELECTRONICS CORPORATION: 1250 Valley Brook Ave. Lyndhurst, N.J. 07071 U.S.A. 333 West Alondra Blvd. Gardena, California 90247 U.S.A.

Segment

3036 Koapaka St. Honolulu, Hawaii 96819 U.S.A. SANSUI AUDIO EUROPE N.V.:

FAST

MS 1

MS 2

MS 3

VSS

VDD

TIMER OFF IMPUT

TIMER ON INPUT

TIMER OUTPUT

SLEEP OUTPUT

MINS-c

MINS-d

32

31

30

29

28

27

26

25

24

23

22

TOP VIEW

HRS-e

10 MINS-f

10 MINS-g

10 MINS-b

10 MINS-e

10 MINS-c

MINS-1

MINS-g

MINS-a

MINS-b

MINS-e

15

17

18

19

10 MINS-a & d

North Trade Bldg (9th floor) Noorderlaan 133-Bus 1,2030 Antwerp, Belgium Arabella center, 6 Frankfurt AM Main, Lyoner Strasse 44-48, West Germany SNASUI AUDIO EUROPE S.A.:

AM PM

22 24 23 19 20

Ш

(b, c)

(9, 10)

b С

SANSUI ELECTRIC COMPANY LTD.: 14-1, Izumi 2-chome, Suginamiku, Tokyo 168 Japan PHONE: (03) 323-1111/TELEX: 232-2076

31 32

d e f g Ground Heater Heater

a, b, c, d, e, f, g

13 14 16 15 17 11 12

H

27 28 30 31 29 25 26 18

Cd1, Cd2 (a, b)

Ш

RD12EB